



©Billet Rides, All Rights Reserved

Assembly Instructions (Rectangular)

Spin mirror clockwise to orientate for Driver or Passenger Side

1. Remove the 4 Allen heads at bottom of the base.
2. Separate the base from the stem.
3. Place gasket on your door with base on top.
4. Secure base to your door using factory screws.
5. Insert stem into the base.
6. Re-secure stem to base using 4 Allen heads and Loctite.
7. Adjust mirror and tighten 6 Allen heads tensioning the pivot ball if desired.